Assembly Instructions





What's in the Box



Part #1 - 62" Steel Tube - 1pc


Part #2 – 30" Steel Tube - 2pcs

Part #3 – Steel Mounting Plates - 2pcs


Part #4 – 0.5" x 3.5" Bolt w/ lock washer and nut - 6pcs

Assemble Hanging Bracket

Assemble the Bracket so the distance between hole centers A and B are the distances indicated in the table at the end of this document. Select the model of Magnetic Sweeper you purchased and assemble the bracket to these dimensions. If the exact measurement is not available adjust to the nearest size.




Assembly Details



Helpful Tips

After your Suspension Bracket is attached to the vehicle by way of additional accessories purchased from Bluestreak, or by way of your own additional fabrication you need to suspend the magnet from the Bracket. Use the assembly/ installation instructions provided with your magnetic sweeper.



All Magnets should primarily be suspended with 4 chains from the Steel Mounting Plates (Part #3) as shown above. Wheeled sweepers are typically recommended to have the wheels set up ½" off of the ground, and non wheeled sweepers should always be kept as close to the ground as possible without hitting the ground when moving.

Additional suspension points on the ends of the Bracket are provided primarily for sweepers with lifting actuators to attach to. However you may use them to attach additional hanging chains.




Tip #1: If your magnet appears to be hanging crooked it is possible the Steel Mounting Plates have not been assembled perfectly square. To correct this simply loosen both bolts in each of the 2 Steel Mounting Plates and the problem will correct itself. Retighten the bolts previously loosened.

If the problem still exists it may be possible 1) your chains are not the same length 2) There is a twist in one or more of the chains (this changes the length) 3) The chains are not uniformly connected at all ends (all 4 chains need to be the same length and have the same orientation).

Helpful Tips



Tip #2: Suspend the Sweeper with the Chains all positioned so they are on the inside of the Steel Mounting Plates as shown above.



Tip #3: The Ground Clearance can be fine tuned by changing the locations of the Steel Mounting Plates (Part #3) inward or outwards, to ensure your magnet is perfectly level with the ground. It is also possible your vehicle or receiver hitch (if used) may not be perfectly level in all directions.

| Hanging Sweeper Model | Size | Hanging Bracket Model | Dim A | Dim B | Dim C |
|--------------------------|------|--------------------------|-------|-------|-------|
| Aether | 62 | С | 34 | 56 | 24 |
| Aether | 74 | С | 38 | 68 | 24 |
| Aether | 86 | С | 42 | 80 | 24 |
| Aether | 98 | С | 46 | 92 | 24 |
| Alpha | 86 | С | 42 | 80 | 24 |
| Alpha | 98 | С | 46 | 92 | 24 |
| Eiger 3x3 | 38 | А | 26 | N/A | 12.5 |
| Eiger 3x3 | 50 | А | 32 | 46 | 12.5 |
| Eiger 3x3 | 62 | В | 38 | N/A | 12.5 |
| Eiger 3x3 | 74 | В | 44 | 70 | 12.5 |
| Eiger 3x3 | 86 | В | 50 | 82 | 12.5 |
| Eiger 3x3 | 98 | В | 56 | 94 | 12.5 |
| Eiger 4.5x4.5 | 38 | А | 26 | 34 | 12.5 |
| Eiger 4.5x4.5 | 50 | А | 32 | 46 | 12.5 |
| Eiger 4.5x4.5 | 62 | В | 38 | N/A | 12.5 |
| Eiger 4.5x4.5 | 74 | В | 44 | 70 | 12.5 |
| Eiger 4.5x4.5 | 86 | В | 50 | 82 | 12.5 |
| Eiger 4.5x4.5 | 98 | В | 56 | 94 | 12.5 |
| Gobie | 14 | N/A | N/A | N/A | N/A |
| Gobie | 20 | N/A | N/A | N/A | N/A |
| Gobie | 26 | А | 20 | N/A | 12.5 |
| Gobie | 32 | Α | 23 | N/A | 12.5 |
| Gobie | 38 | А | 26 | N/A | 12.5 |
| Gobie | 44 | А | 29 | N/A | 12.5 |
| Gobie | 50 | А | 32 | N/A | 12.5 |
| Gobie | 56 | В | 35 | N/A | 12.5 |
| Gobie | 62 | В | 38 | N/A | 12.5 |
| Gobie | 68 | В | 41 | N/A | 12.5 |
| Gobie | 74 | В | 44 | N/A | 12.5 |
| Gobie | 80 | В | 47 | N/A | 12.5 |
| Gobie | 86 | В | 50 | N/A | 12.5 |
| Gobie | 92 | В | 53 | N/A | 12.5 |
| Gobie | 98 | В | 56 | N/A | 12.5 |
| ISO | 62 | А | 22 | 64 | 12.5 |
| ISO | 74 | В | 34 | 76 | 12.5 |
| ISO | 86 | В | 46 | 88 | 12.5 |
| ISO | 98 | В | 58 | 100 | 12.5 |
| Khamsin | 62 | А | 22 | 62 | 12.5 |
| Khamsin | 74 | В | 34 | 74 | 12.5 |
| Khamsin | 86 | В | 46 | 86 | 12.5 |
| Khamsin | 98 | В | 58 | 98 | 12.5 |

| Hanging Sweeper Model | Size | Hanging Bracket Model | Dim A | Dim B | Dim C |
|--------------------------|------|--------------------------|-------|-------|-------|
| PYR 3x3 | 38 | Α | 26 | N/A | 12.5 |
| PYR 3x3 | 50 | Α | 32 | 46 | 12.5 |
| PYR 3x3 | 62 | В | 38 | 58 | 12.5 |
| PYR 3x3 | 74 | В | 44 | 70 | 12.5 |
| PYR 3x3 | 86 | В | 50 | 82 | 12.5 |
| PYR 3x3 | 98 | В | 56 | 94 | 12.5 |
| PYR 4.5x4.5 | 38 | Α | 26 | N/A | 12.5 |
| PYR 4.5x4.5 | 50 | Α | 32 | 46 | 12.5 |
| PYR 4.5x4.5 | 62 | В | 38 | 58 | 12.5 |
| PYR 4.5x4.5 | 74 | В | 44 | 70 | 12.5 |
| PYR 4.5x4.5 | 86 | В | 50 | 82 | 12.5 |
| PYR 4.5x4.5 | 98 | В | 56 | 94 | 12.5 |
| Remoras | 38 | N/A | N/A | N/A | N/A |
| Remoras | 50 | N/A | N/A | N/A | N/A |
| Remoras | 62 | N/A | N/A | N/A | N/A |
| Remoras | 74 | N/A | N/A | N/A | N/A |
| Remoras | 86 | N/A | N/A | N/A | N/A |
| Remoras | 98 | N/A | N/A | N/A | N/A |
| Wrasse 2x5 | 26 | Α | 20 | N/A | 12.5 |
| Wrasse 2x5 | 38 | Α | 26 | N/A | 12.5 |
| Wrasse 2x5 | 50 | Α | 32 | N/A | 12.5 |
| Wrasse 2x5 | 62 | В | 38 | N/A | 12.5 |
| Wrasse 2x5 | 74 | В | 44 | N/A | 12.5 |
| Wrasse 2x5 | 86 | В | 50 | N/A | 12.5 |
| Wrasse 2x5 | 98 | В | 56 | N/A | 12.5 |
| Wrasse 3x3 | 26 | Α | 20 | N/A | 12.5 |
| Wrasse 3x3 | 38 | Α | 26 | N/A | 12.5 |
| Wrasse 3x3 | 50 | Α | 32 | N/A | 12.5 |
| Wrasse 3x3 | 62 | В | 38 | N/A | 12.5 |
| Wrasse 3x3 | 74 | В | 44 | N/A | 12.5 |
| Wrasse 3x3 | 86 | В | 50 | N/A | 12.5 |
| Wrasse 3x3 | 98 | В | 56 | N/A | 12.5 |
| Wrasse 4.5x4.5 | 26 | А | 20 | N/A | 12.5 |
| Wrasse 4.5x4.5 | 38 | А | 26 | N/A | 12.5 |
| Wrasse 4.5x4.5 | 50 | А | 32 | N/A | 12.5 |
| Wrasse 4.5x4.5 | 62 | В | 38 | N/A | 12.5 |
| Wrasse 4.5x4.5 | 74 | В | 44 | N/A | 12.5 |
| Wrasse 4.5x4.5 | 86 | В | 50 | N/A | 12.5 |
| Wrasse 4.5x4.5 | 98 | В | 56 | N/A | 12.5 |

Bluestreak Equipment • 1645 Hwy #3, Delhi, Ontario, Canada N4B 2W6

www.bluestreakequipment.com