Assembly Instructions







Bluestreak Equipment 1645 Hwy #3, Delhi Ontario, Canada N4B2W6

Step 1. Remove Items from Pallet

(Step 1) Remove Items from Pallet





Step 2. Insert Tongue into Receiver

(Step 2) Insert tongue into receiver





Step 3. Install Bent Pin and Clip

(Step 3) Install Bent Pin and Clip





Step 4. Rotate on Pallet

(Step 4) Rotate on pallet so axle stubs are away from pallet





Step 5. Remove Clips on Each End

(Step 5) Remove clips on each end





Step 5. Image of Clip Removed

(Step 5) Image of clip removed





Step 6. Install Wheel on Axle Stub

(Step 6) Install wheel on axle stub and insert clip that was just removed





Step 7. Turn the Top Link

(Step 7) Turn the top link (height adjuster) until wheels are touching ground





Step 8. Put Top Link Adjuster into Holder

(Step 8) Put top link adjuster into holder, then wheel sweeper off the pallet (Assembly Complete)





