





What's in the box




4 inch ruler to measure bolt size



Item A B C D E F G H I J K L M N O	Quantity 2pcs 1pc 1pc 4pcs 3pcs 2pcs 11pcs 22pcs 14pcs 4pcs 1pc 1pc 1pc 1pc 2pcs	Description 1/2" Wheel Bolts and Flange Nuts 1/4" x 1 1/4" Hex Bolt 1/4" x 1 3/4" Hex Bolt 1/4" x 2" Hex Bolts 1/4" x 2 1/4" Hex Bolts 1/4" x 2 3/4" Hex Bolts 1/4" Hex Nuts 1/4" Washers Small Nylon Flange Bushings Large Nylon Flange Bushings Upper Y- handle Release Lever Release Rod Lower Y-handle Arms Magnetic Sweeper Base
M	1pc 1pc	Release Rod
N O P Q	2pcs 1pc 1pc 2pcs	Lower Y-handle Arms Magnetic Sweeper Base Magnet Assembly 6" Plastic Wheel
R	4pcs	Handle Mounting Brackets

Bluestreak


Tools Needed:




Œcko Series™

by Bluestreak equipment

For further assembly help please view the assembly video online at: www.bluestreakequipment.com






Bushings (Item J).
b) On the lower end of the Lower Y-handle Arms (Item N) (same end that was fastened in (Step 1) Insert one Small Nylon Flange Bushing (Item I) into each

the 2 pairs of uprights Insert 4 Large Nylon Flange

- one Small Nylon Flange Bushing (Item I) into each side of the Lower Y-Handle Arms (Item N), 4 pcs total.
- c) Slide Magnet Assembly (Item P) over top of Lower Y-handle arms (Item N) and attach each side using 1 Hex Bolt (Item E), 2 Washers (Item H) and one Hex Nut (Item G). Tighten bolt gently. Over tightening bolt will interfere with operation of sweeper and produce a "squeaky" sound.



Œcko Series™


STEP THREE - Upper Y-Handle Assembly

- a) Attach Upper Y-handle (Item K) to Lower Y-handle Arms (Item N) using 2 Hex Bolts (Item F), 4 Washers (Item H), and 2 Hex Nuts (Item G). Tighten these 2 bolts firmly using two 7/16 wrenches, and also tighten the bolts installed in Step 1.
- b) Insert one Small Nylon Flange Bushings (Item I) into each of the four holes of Release Lever (Item L). Insert one Small Nylon Flange bushings (Item I) into each of the 2 holes of Upper Y-Handle (Item K).
- c) Attach Release Lever (Item L) to Upper Y-Handle (Item K) using one Hex Bolt (Item E), 2 Washers (Item H), and 1 Hex Nut (Item G). Tighten bolt gently. Over tightening bolt will interfere with pivoting operation of sweeper and produce a "squeaky" sound.
- d) Insert 2 Nylon Flange Bushing (Item I), one in each side of Release Rod (Item M). Attach Release Rod (Item M) to Release Lever (Item L) using one Hex Bolt (Item C), 2 Washers (Item H), and 1 Hex Nut (Item G).



STEP FOUR

Lower Release Assembly






STEP FOUR - Lower Release Assembly

Insert 2 Small Nylon Flange Bushing (Item I), one in each side of Release Rod (Item M). Attach Release Rod (Item M) to Magnet Assembly (Item P) using one Hex Bolt (Item B), 2 Washers (Item H), and 1 Hex Nut (Item G). Tighten bolt gently. Over tightening bolt will interfere with operation of sweeper and produce "squeaky" sound.







STEP FIVE- Wheel Assembly Insert ½" Wheel Bolts (Item A) through 6" Plastic Wheel (Item Q), through desired hole location on Magnetic Sweeper Base (Item O) and tighten on flanged hex nut. Tighten firmly using one 3/4" and one 9/16" wrench. Repeat for opposite side.